The prerequisites for reading this accessory are:

You can already use SETP\_Tool to connect, read, and modify VS4XX parameters (see "VS1xx\_VS4XX (EUR)User Manual V1.24 For HW201 sf300.pdf").

### Data transmitter

Step 1: Set the data transmission mode of VS4XX

In Setp\_Tool, change the "Data transmission Mode" in the "Automation" panel to "LORA", as shown below.



Note: After modifying the parameters, be sure to click the "Save Parameters" button in SETP\_Tool. (The same below)



## ➤ Step 2: Modify the LORA parameters



It's a good idea to keep the default values.

Note: In any case, the LORA parameters of the sender and receiver must be exactly the same.

# Data receiver

If you have a LORA receiver, configure the LORA parameters of the receiver to be exactly the same as the transmitter.

If you do not have a LORA receiver, you can make VS4XX a receiver by modifying the parameters as follows:

### > Step 1: Modify the working mode

Modify "Next time start working mode" Is "Set Mode".



After this parameter is modified, VS4XX will automatically enter "Parameter Setting Mode" at each startup, and the indicator will flash quickly.

Step 2: Set the data transmission mode of VS4XX

Time Scan Interval  Data storage interval  Automatic data transmission interval	READ	WRITE
Automatic data transmission interval	READ	WRITE
	READ	WRITE
and the second s		
Packet protocol HEX	READ	WRITE
Data transmission mode		
Data transmission mode Lora	READ	WRITE

#### Step 3: Modify the LORA parameters



Note: To prevent the receiver from shutting down automatically, you can set a read instruction to VS4XX every 1 minute in the upper right corner of the SETP\_Tool interface (in parameter mode, VS4XX will not start the automatic shutdown process as long as it receives any data).

### **TEST**

VS4XX automatically starts every period of time (the default is 8 minutes), collects sensor data, then sends data and shuts down.

In particular, you can use VS4XX's [Test] button to force a data transmission.



When the receiver receives the data, it outputs the received data at the RS232 interface. If you use VS4XX as the receiver, you can see the content of the received data on the left side of the SETP\_Tool interface.

When VS4XX outputs LORA data from RS232, it is prefixed with "LoraRecev:\t".

There are three packet formats for VS4XX, please refer to "VS10x\_VS4xx Data Protocol Description.pdf"  $_{\circ}$ 

